

Handlebar Adjustment Guide

1, Remove these clamp bolts on the handle bar on both sides circled in red, should be 4 bolts (should be a 10mm socket size).



2, Remove the top to the clamp block (in green below)



3, Set the bar in the recessed area.



4, Put the top clamp block back on and screw the bolts in, but do not tighten down all the way, just tighten enough so that the handle bar will move a little so you can position it comfortably for you to ride.



5, Put the handle bars in a position that is comfortable for you to reach and drive, tighten the bolts down tight enough so that your handle bar does not move. That's it!

Also please check both of your wheels, sometimes there will be a cable holding the wheel in place and you will need to remove it before moving the scooter.



Check for a cable on either wheel and remove. The cable will prevent the scooter from moving.